CLEANING DEBRIS TRAY, FLOAT SHUT OFF, SQUEEGEE & P-TRAP

FOR SAFETY: Before working on machine, park machine on level surface, turn off machine and remove key.

A. Remove and clean the float shut-off screen.



B. Remove debris tray from machine. Dispose of debris in waste container and rinse out tray. Reinstall debris tray.



- **C.** Remove squeegee assembly and wipe squeegee blades clean after each use.
- **D.** Inspect blades for wear and damage.
- **E.** Rotate blades if worn.



F. Remove the drip tray cover and clean reservoir.

