



## INSTRUCTION BULLETIN

No. 340129  
Machine: 4300  
Published: 12-98/00  
System: OPTIONS

**NOTE: DO NOT DISCARD the Parts List from the Instruction Bulletin. Place the Parts List in the appropriate place in your machine manual for future reference. Retaining the Parts List will make it easier to reorder individual parts and will save you the cost of ordering an entire kit.**

*NOTE: Numbers in parenthesis ( ) are reference numbers for parts listed in Bill of Materials.*

Installation instructions for kit number 367607

### **SYNOPSIS / PROBLEM:**

This kit contains the parts needed to install a fire extinguisher kit on the model ATLV 4300  
Please follow step-by-step instructions.

### **SPECIAL TOOLS / CONSIDERATIONS: Drill, .218in. drill bit**

(Estimated time to complete: .5 hour)

### **PREPARATION:**


(Refer to FIG. 1)

**FOR SAFETY: Before leaving or servicing machine, stop on level surface and set parking brake. Then turn off machine and remove key.**

### **INSTALLATION:**

(Refer to FIG. 1)

1. Using fire extinguisher mounting bracket as a template, mark two mounting hole locations on the left hand, outside of machine roll bar. Mark the top hole 14 inches up from the base of the roll bar. (Refer to FIG. 1)
2. Drill two .218in. (7/32) holes in newly marked positions. (Refer to FIG. 1)
3. Mount fire extinguisher (1) to machine with screws (2), in new mounting holes.  
(Refer to FIG. 1)



**FIG. 1 - FIRE EXTINGUISHER KIT INSTALLATION**

**BILL OF MATERIALS FOR FIRE EXTINGUISHER KIT 367607**

Ref.	TENNANT Part No.	Description	Qty.
1	25312	Fire extinguisher	1
2	361339	Scr-hxfmgm, M6 x 16mm	2

TENNANT COMPANY  
P. O. Box 1452  
Minneapolis, MN 55440-1452