



# INSTRUCTION BULLETIN

No. 340219  
Machine: 6200E  
Published: 9-99/00  
System: ELECTRICAL

**NOTE: DO NOT DISCARD the Parts List from the Instruction Bulletin. Place the Parts List in the appropriate place in your machine manual for future reference. Retaining the Parts List will make it easier to reorder individual parts and will save you the cost of ordering an entire kit.**

*NOTE: Numbers in parenthesis ( ) are reference numbers for parts listed in Bill of Materials.*

Installation instructions for kit number 383967

## **SYNOPSIS / PROBLEM:**

This kit contains the parts needed to replace the stop switch on the model 6200E sweeper. Please follow step-by-step instructions.

## **SPECIAL TOOLS / CONSIDERATIONS: NONE**

(Estimated time to complete: 0.5 hour)

## **PREPARATION:**

(Refer to FIG. 1 and 2)

**FOR SAFETY: Before leaving or servicing machine, stop on level surface and set parking brake. Then turn off machine and remove key.**

1. Disconnect battery cables from machine.
2. Locate the circuit breaker panel in front of the operator's compartment.




**WARNING: Always disconnect battery cables from machine before working on electrical components.**

## **INSTALLATION:**

(Refer to FIG. 1 and 2)

1. Remove and set aside the circuit breaker panel mounting hardware. Open the circuit breaker panel.
2. Remove the plug (76888) from the instrument panel.
3. Plug the new stop switch (1) and contact switch (2) assembly into the main wiring harness under the control panel. (Refer to FIG. 1 and 2)
4. Assemble the new stop switch (1) in the control panel with the securing nuts, washers and cap. (Refer to FIG. 2)
5. Close the circuit breaker panel, and secure with the set aside mounting hardware.





**FIG. 2 - STOP SWITCH INSTALLATION**

**BILL OF MATERIALS FOR STOP SWITCH KIT 383967**

Ref.	TENNANT Part No.	Description	Qty.
1	78553	Switch	1
2	65665	Contact, Switch	1

TENNANT COMPANY  
P. O. Box 1452  
Minneapolis, MN 55440-1452