



S960

Ride-on sweeper

COMMON PARTS & CONSUMABLES

Only genuine Tennant parts can ensure peak performance
for the life of your equipment.

Serial # _____

Brushes

- Easy installation helps reduce machine downtime.
- Optimal operation with Tennant machines, maximizing cleaning effectiveness in one pass.

PART DESCRIPTION		PART #
	Cylindrical Brush, 700*320	TN5100322
	Side Brush	TN5100320

Squeegee

- Economy Gum Rubber is cost-effective option for smooth, indoor floors, made of a combination of natural material and fillers.

	PART DESCRIPTION	PART #
SIDE	Rubber Squeegee	TN5100354
REAR	Rubber Squeegee	CN5006432

General Maintenance

- Tennant True® parts are designed to fit your Tennant machine, helping achieve better cleaning performance and reducing machine downtime.

PART DESCRIPTION		PART #
	Filter	TN5100357
	Filter, 80 Mesh	CN5004741
	Circuitbreaker, 3A, Insert	CN5004454
	Circuitbreaker, 10A, Insert	CN5006408
	Fuse, 100A	CN5001636
	Sealing Strip, W17, H30, 1-3.5MM	CN5006464
	Hopper Wheel, 5 inches	TN4100405
	Drive Belt, XPA800	CN4001190
	Load-Bearing Wheel, 300*100MM	CN5006463