

# **S960**

# Ride-on sweeper

COMMON PARTS & CONSUMABLES

Only genuine Tennant parts can ensure peak performance for the life of your equipment.

<u>Serial #</u>

#### **Brushes**

- Easy installation helps reduce machine downtime.
- Optimal operation with Tennant machines, maximizing cleaning effectiveness in one pass.

PART DESCRIPTION	PART #
Cylindrical Brush, 700*320	TN5100322
Side Brush	TN5100320

## Squeegee

• Economy Gum Rubber is costeffective option for smooth, indoor floors, made of a combination of natural material and fillers.

	PART DESCRIPTION	PART #
SIDE	Rubber Squeegee	TN5100354
REAR	Rubber Squeegee	CN5006432

## **General Maintenance**

 Tennant True<sup>®</sup> parts are designed to fit your Tennant machine, helping achieve better cleaning performance and reducing machine downtime.

PART DESCRIPTION	PART #
Filter	TN5100357
Filter, 80 Mesh	CN5004741
Circuitbreaker, 3A, Insert	CN5004454
Circuitbreaker, 10A, Insert	CN5006408
Fuse, 100A	CN5001636
Sealing Strip, W17, H30, 1-3. 5MM	CN5006464
Hopper Wheel, 5 inches	TN4100405
Drive Belt, XPA800	CN4001190
Load-Bearing Wheel, 300*100MM	CN5006463