



R14 - DAILY OPERATOR CHECKLIST

PRE-OPERATION CHECKLIST

- Vacuum floor and remove any debris
- Check battery meter charge level indication
- ReadySpace Cleaning: Check rollers for wear
- Restorative Extraction Cleaning: Check the brushes for wear
- Inspect spray nozzles for proper spray pattern
- ReadySpace Cleaning: Inspect roller vacuum shoes for debris
- Restorative Extraction Cleaning: Inspect the extraction shoe for debris
- Make sure the recovery tank shut off float switch is clean
- Make sure solution tank is filled with only water, no cleaning detergents

POST-OPERATIONAL CHECKLIST

- Drain and rinse out the recovery and solution tanks after every use
- Rinse out the recovery tank and the shut off float switch with clean water
- Rotate the ReadySpace rollers end-for-end every 10 hours of use
- Remove any debris build-up from the underside of the scrub head
- Remove the front and rear roller vacuum shoe covers and remove any debris
- Remove any entangled carpet fibers and debris from the brushes
- Remove any debris lodged in the restorative extraction vacuum shoe
- Inspect the spray tips for proper spray pattern
- Clean the machine housing with an all purpose cleaner and damp cloth
- Check battery charge level and charge the batteries as required
Before charging the batteries, check the electrolyte level in each battery cell
 - *To prolong the battery life, ONLY recharge the batteries after a total of 30 minutes of use or more.*

List below any problems that occurred during operation.

OPERATOR _____

DATE _____

SUPERVISOR _____

DATE _____