



Operative Instruction: T681

1. Turn on the machine, activate the Auto program to enable solution delivery to the brush deck.

Press and keep pressed the solution Select switch for 5 sec to activate the Chem-Dose function. The red LED for chem-dose illuminates, display turns from hour counter to CDxx to indicates chem dose % set.



2. To change the Chem dose % value press the Select switch until only the Chem-Dose red LED illuminates. Now the chem % can be changed.



3. Use the + and – switches for solution flow adjustment to change the CD%. Values can be set from CD0 to CD10. After 10 sec the water flow selection will be activated automatically. Machine is ready to use.



CD0	0,5%	CD6	5,5%
CD1	1,0%	CD7	6,0%
CD2	2,0%	CD8	6,5%
CD3	3,0%	CD9	7,0%
CD4	4,0%	CD10	7,5%
CD5	5,0%		